
KLINGERtop-chem® 2000 Oxygen Service Gaskets

While wearing surgical latex gloves, the KLINGERtop-chem® 2000 gaskets must first be cleaned with Trichloroethylene [79-01-6] solvent. After cleaning, gaskets must be completely dried with oil-free air. Finished gaskets shall be placed into a plastic bag marked "oxygen serviced".

The ability of a gasket material to make and maintain a seal depends not only on the quality of the gasket material, but also on medium being sealed, the flange design, the amount of pressure applied to the gasket by the bolts and how the gasket is assembled into the flanges and tightened.

For product safety information, warranty and damage limitations, refer to the Material Safety Data Sheet (MSDS).